|      |  | 1-5. | Refueling                     | 70  |
|------|--|------|-------------------------------|-----|
| 1    | Before driving                             |      | Opening the fuel tank cap     | 70  |
| 1-1. | Key information20                          | 1-6. | Theft deterrent system        | 73  |
|      | Keys 20                                    |      | Immobilizer system            | 73  |
|      | •  |      | Alarm                         | 75  |
| 1-2. | Opening, closing and locking               |      | Theft prevention labels       |     |
|      | the doors and trunk22                      |      | (U.S.A.)                      | 77  |
|      | Smart access system with push-button start | 1-7. | Safety information            | 78  |
|      | Wireless remote control 34                 |      | Correct driving posture       | 78  |
|      | Doors                                      |      | SRS airbags                   | 80  |
|      | Trunk 42                                   |      | Front passenger occupant      |     |
|      |  |      | classification system         | 92  |
| 1-3. | Adjustable components                      |      | Child restraint systems       | 98  |
|      | (seats, mirrors,                           |      | Installing child restraints   | 102 |
|      | steering wheel)45                          |      |                               |     |
|      | Front seats45                              | 2    | When driving                  |     |
|      | Driving position memory                    |      |                               |     |
|      | system 47                                  | 0.1  | D                             | 110 |
|      | Head restraints                            | 2-1. | Driving procedures            |     |
|      | Seat belts                                 |      | Driving the vehicle           |     |
|      | Steering wheel60                           |      | Engine (ignition) switch      |     |
|      | Inside rear view mirror 61                 |      | Automatic transmission        |     |
|      | Outside rear view mirrors 62               |      | Turn signal lever             |     |
|      |  |      | Parking brake                 | 131 |
| 1-4. |  | 0.0  |                               | 400 |
|      | windows and moon roof 64                   | 2-2. | Instrument cluster            |     |
|      | Power windows                              |      | Gauges and meters             | 132 |
|      | Moon roof 67                               |      | Indicators and warning lights | 136 |
|      |  |      | Multi-information display     | 139 |

| 2-3. | Operating the lights and windshield wipers142 | 3    | nterior features                                  |   |
|------|---|------|---|---|
|      | Headlight switch                              | 3-1. | Using the touch screen                            | 1 |
| 2-4. | Using other driving systems 150               | 3-2. | Using the air conditioning system and defogger217 | 2 |
|      | Cruise control                                |      | Automatic air conditioning system                 | 3 |
|      | control                                       | 3-3. | view mirror defoggers                             |   |
|      | AVS (Adaptive Variable Suspension System)     | 3 3. | Audio system type                                 | 4 |
|      | Driving assist systems                        |      | Using the cassette player                         | 5 |
| 2-5. | Driving information                           |      | Playing MP3 and WMA discs                         |   |
|      | Vehicle load limits                           |      | Playing DVD video/audio254                        | 6 |
|      | Trailer towing                                |      | Playing video CD                                  | 7 |
|      |   |      | Optimal use of the audio/video system             | , |
|      |   |      | Using the AUX adapter                             |   |

## **TABLE OF CONTENTS**

Index

| 2 1          |  |                  |  |  |       |
|--------------|--|------------------|--|--|-------|
| <b>3-4</b> . | Using the hands-free system (for cellular phone) | . 291            | 1  | Maintenance and care                         |       |
|              | Hands-free system (for cellular phone)           | . 291 4          | -1.  | Maintenance and care                         | 388   |
|              | Using the Bluetooth®                             | 296              |  | Cleaning and protecting the vehicle exterior | 388   |
|              | Setting the hands-free system                    |                  | Cleaning and protecting the vehicle interior | 39   |       |
| 3-5.         | Using the interior lights                        | 337 <sub>4</sub> | -2.  | Maintenance                                  | .39   |
|              | Interior lights list                             | 337              |  | Maintenance requirements                     | . 39  |
| <b>.</b> ,   |  |                  |  | General maintenance                          |       |
| 3-6.         | Using the storage features                       |                  |  | Emission inspection and                      |       |
|              | List of storage features                         | 340              |  | maintenance (I/M)<br>programs                | . 39  |
| 3-7.         | Other interior features                          | 347              |  |  |       |
|              | Sun visors                                       | 347 <b>4</b>     | -3.  | Do-it-yourself                               |       |
|              | Vanity mirror                                    | 348              |  | maintenance                                  | 40    |
|              | Clock  | 349              |  | Do-it-yourself service                       |       |
|              | Outside temperature                              |                  |  | precautions                                  |       |
|              | display  | 350              |  | Hood   |       |
|              | Ashtrays   | . 351            |  | Positioning a floor jack                     |       |
|              | Cigarette lighter                                | 352              |  | Engine compartment                           |       |
|              | Power outlet                                     | 353              |  | Tires  |       |
|              | Seat heaters/ventilators                         | 354              |  | Tire inflation pressure                      |       |
|              | Armrest  | 356              |  | Wheels                                       |       |
|              | Rear sunshade                                    | 357              |  | Air conditioning filter                      |       |
|              | Floor mats                                       | 359              |  | Electronic key battery                       | . 44  |
|              | Trunk features                                   | 360              |  | Checking and replacing                       |       |
|              | Garage door opener                               | 363              |  | fuses  |       |
|              | Compass  | 369              |  | Headlight aim                                |       |
|              | Lexus Link System                                | 373              |  | Light bulbs                                  | . 4/( |

## When trouble arises Vehicle specifications 5-1. Essential information ............... 478 6-1. Specifications...... 540 If your vehicle needs Maintenance data to be towed...... 478 (fuel, oil level, etc.)..... 540 If you think something is Fuel information...... 553 wrong......484 Tire information ...... 556 Fuel pump shut off system ...... 485 Event data recorder...... 486 6-2. Customization ...... 569 Customizable features ...... 569 5-2. Steps to take in an 3 emergency......488 6-3. Initialization ...... 575 If a warning light turns on or a Items to initialize ...... 575 warning buzzer sounds... ..... 488 If a warning message is displayed...... 497 For owners If you have a flat tire (Vehicles with standard tires)...... 512 Reporting safety defects for If you have a flat tire (Vehicles U.S. owners...... 578 with run-flat tires)...... 522 Seat belt instructions for If the engine will not start ......... 523 Canadian owners If the shift lever cannot be (in French)...... 579 shifted from "P" ...... 524 If you lose your keys......525 Index If the electronic key does not operate properly ...... 526 If the 12 volt battery is Abbreviation list ...... 582 discharged ...... 529 If your vehicle overheats....... 533 Alphabetical index..... 584 If the vehicle becomes stuck...... 536 What to do if...... 594